VEL 1

mediate 3. Craftsr

2 Feet Tall!


Length: 24" (61cm) Diameter: 1.637" (41.6mn Weight: 2.2 oz. (62.4g)

Reco A8-3 B6-4 ngines: B6-2 (First flight)






Big Bertha KIT NO.1223 SKILL LEVEL 1




A SUBSIDIARY OF DAMON

PENROSE, COLO. BI240


ASSEMBLY INSTRUCTIONS



Measure 2-1/2" from one end of the engine tube (part E) and cut a 1/8" wide slit. Apply a 1-1/2" long line of glue to the tube as shown. Push one end of the engine hook (part G) into the slit and press the main part of the hook into the glue. Wrap at least three layers of masking tape around the tube and the engine hook at approximately the mid point of the hook.



□ 2 Separate the adapter rings from the diecut cards (part F) and glue the rings together in pairs. When the glue has set, cut a 1/8"X1/8" slot into one pair as shown above. Slide the slotted ring onto the engine hook end of the tube until 1/4" of the tube is through. Make sure engine hook is free to move up and down in the 1/8"X1/8" slot. Slide the other ring onto the front of the tube until about 1/16" of the tube is through. Apply a line of glue at the ring tube joint on both sides of each ring. Be sure not to get glue on the engine hook where it passes through the ring. Let this assembly dry completely.




sheet (part M). Lay the pattern from the pattern sheet (part M). Lay the pattern on the balsa fin stock (part D) with the leading edge flush with the side edge of the sheet as shown above. Grain indicates arrows should parallel the grain in the wood. Trace out four fins, two on each sheet of


ROUND LEADING, TIP, AND TRAILING EDGES



balsa. Cut out the fins carefully. Sand each side smooth and round all edges except the root edge of each fin.




4 Check the fit of the engine holder tube assembly into the main body tube (part C). The front rings should be a smooth slide fit. The rear rings may be a tight slide fit, for they must only travel 1/4" into the body tube. Sand rings as needed to obtain the desired fit. Slide the front rings part way into the body tube and apply a line of glue about 1/4" inside the body tube. Slide the engine holder assembly in until the rear rings are 1/4" inside the body tube. Rub a line of glue around the ring-tube joint and support the body tube in a vertical position until this assembly is dry.




Out out the fin spacing guide, wrap it around the rear end of the body and mark the tube at each of the arrow points. Draw a straight connecting line between each matching front and rear mark.







Aub a line of glue into the root edge of each fin and allow to dry. Glue the fins to the body tube with the edge of the fin along one of the lines drawn in step 5. Align the fin so it projects straight away from the body tube. Following the same procedure, attach the other three fins. Do not set the rocket on its fins while the glue is wet.



Glue the launching lug to the body tube so its rear is even with the front of the fins and is halfway between two fins as shown. Sight along the tube and align the lug so it runs parallel to the body tube.




B Cut out the shock cord mount. Prefold it on the dotted lines, then flatten it out again. Smear glue over section 1. Lay the end of the shock cord into place and fold section 1 over. Apply glue to the back of section 1 and the exposed part of section 2 and fold again. Clamp the unit together with your fingers while the glue sets. Apply glue to the inside of the body tube over an area approximately 1" to 1-1/2" from the front end. The glue should cover a shape approximately the same as the shock cord mount. Press the mount onto the glue and hold it until the glue sets.




□ 10 Cut out the parachute on its edge lines as indicated on the plastic. Cut three 36 inch lengths of shroud line. Attach line ends to the surface of the parachute with tape discs as shown above. Pass shroud line loops through nose cone lug, pass parachute through loops and pull lines tight on lug. Set this knot with a drop of glue. Tie shock cord securely to nose cone lug.



A fillet is a smooth joint built up between body and fin by applying glue along the joint and smoothing the glue with a finger.



11 Reinforce the fin and launch lug joints with glue. Holding the rocket horizontally (level), apply a line of glue to both sides of each joint. Smooth out the glue with your finger. Keep the rocket level until the glue dries.



SHAKE CAN PERIODICALLY

When all glue on the outside of the model is dry, prepare the balsa parts for painting. Apply at least two coats of sanding sealer to the fins. Let dry and sand lightly between coats. Do this until the tiny holes in the wood are filled and everything looks and feels smooth.

Push the parachute into the body tube, packing the shroud lines and shock cord over it. Push the base of the nose cone into the forward end of the body tube.

Give the rocket at least one clean base coat of glossy white enamel, then give it two or more coats of the final colors to produce the best appearance.

Trim color may be applied with tape, decals, or sprayed on.

Be sure to follow the *HIAA-NAR Model Rocketry Safety Code when carrying out your model rocket activities.

*HIAA-NAR - Hobby Industry Association of America

National Association of Rocketry

PREFLIGHT PREPARATION AND RECOVERY TIPS


WADDING

This material is used to protect your parachute from the heat of the engine's ejection charge, Recovery Wadding (Cat. No. 2274) is flame resistant, thus eliminating the possibility of recovery system failure.

For maximum efficiency use enough wadding to fill the rocket body tube for a distance of twice the body diameter. Usually four or five squares will be adequate for this model rocket. When preparing the rocket for flight, crumple the wadding loosely to get the maximum bulk from it and still obtain a good seal against the wall of the tube. Pack the 'chute in over the wadding,

PARACHUTE

Fold the parachute into a triangular shape. Roll 'chute tightly as shown and wrap shroud lines around it. If 'chute is too large, unroll and repack until it slides easily into the rocket. A very tight fit may prevent parachute from ejecting properly.



NOSE CONE

INSERT AFTER

WADDING

Nose cone should separate easily from rocket body tube, but not be extremely loose. If fit is too tight, sand inside of body tube end and shoulder of nose cone with fine sandpaper.

If nose cone is too loose add a wrapping of transparent tape or masking tape to the shoulder of the nose cone

ENGINE FIT

To activate parachute recovery gear correctly, the engine MUST be held in place SECURELY.

Make sure the end of the engine hook latches securely over the end of the engine.

ENGINE HOOK MUST LATCH SECURELY

IGNITER INSTALLATION


Estes standard Astron igniters are supplied in strips and should be cut apart (Scissors will work.) midway between the coated sections. Bend the igniter at the middle as shown and push it into the engine nozzle as far as it will go.

Estes "Solar" igniters (Cat. No. 2301) are supplied pre-cut and pre-shaped for direct insertion into the engine nozzle. Be sure to push the Solar igniter into the

engine nozzle as far as it will go.

To operate properly, both types of igniters must touch the propellant grain. Spread the leads and apply three squares of masking tape to the nozzle and leads as shown. The eraser on the end of a pencil is good for pressing the tape securely into place.

An Estes standard Astron igniter can also be held in place by rolling a 1" square of flame-proof wadding into a ball and inserting it into the nozzle with a pen or pencil to hold the igniter firmly in place.



BEND AND INSERT IGNITER AND APPLY TAPE



BEND AND INSERT IGNITER TAMP WADDING

LAUNCHING

Lower, the rocket into position on the launch rod. Clean the micro-clips, then clip one to each lead of the igniter. The clips must not touch each other, and the igniter leads must not cross. The rocket may be supported with an empty engine casing to make it easier to attach the clips and to keep the clips from touching the blast deflector plate and short-circuiting.


COUNTDOWN: Give a countdown before launching your rocket. First arm the launch panel. Then begin counting: "5-4-3-2-1-Launch." Press the button and hold it down until the rocket lifts-off.

ATTACH MICRO-CLIPS CLOSE TO NOZZLE



MISFIRE PROCEDURE

Occasionally the igniter will heat and burn into two parts without igniting the engine. This is almost always caused by a failure to install it correctly. Disarm the launch panel, remove the model, clean the igniter residue from the nozzle, and install a new igniter. Follow the launching procedure again.





ESTES INDUSTRIES PENROSE, COLO. 81240 BIG BERTHA PATTERN SHEET 82917



PLEASE READ AND BECOME FAMILIAR WITH THE MODEL ROCKETRY SAFETY CODE ON THE REVERSE SIDE OF THIS CARD. PLEASE SIGN WHERE INDICATED AND KEEP THIS CODE WITH YOU DURING ALL YOUR MODEL ROCKETRY ACTIVITIES.

CAUTION-WARNING: For your safety DO NOT alter, dismantle, or unwrap model rocket engines or their ingredients in any way. Soak unwanted engines in water to destroy.



member of the most exciting rocket club on earth.

Membership includes Viper

Membership includes Viper rocket kit, ID card, membership certificate, iron-on emblem, decal sheet, range box stickers, EAC stationary Technical Manual, copy of Model Rocket News, EAC Product Bulletin, and a variety of exclusive club services.

Lift-off For Fun! Join Today!!

Check the appropriate space on your Rocketeer Registration/Catalog Request coupon for a free membership brochure and application.



ATTENTION ESTES ROCKETEERS

building and launching your own model rockets school address can make th g rockets operate while rocketry teacher's name and address, shows model imply include your teacher' in which more our friends learn catalog Vour explains cience provide cience ou are

conbon.



Model Rocketry Safety Code

- CONSTRUCTION My model rockets will be made of lightweight materials such as paper, wood, plastic and rubber, without any metal as structural parts.
- ENGINES I will use only pre-loaded factory made model rocket engines in the manner recommended by the manufacturer. I will not change in any way nor attempt to reload these engines.
- RECOVERY I will always use a recovery system in my model rockets that will return them safely to the ground so that they may be flown again.
- WEIGHT LIMITS My model rocket will weigh no more than 453 grams (16 ozs.) at liftoff, and the engines will contain no more than 113 grams (4 ozs.) of propellant.
- STABILITY I will check the stability of my model rockets before their first flight, except when launching models of already proven stability.
- LAUNCHING SYSTEM The system I use to launch my model rockets must be remotelly controlled and electrically operated, and will contain a switch that will return to "off" when released. I will remain at least 10 feet away from any rocket that is being launched.
- LAUNCH SAFETY I will not let anyone approach a model rocket on a launcher until I have made sure that either the safety interlock key has been removed or the battery has been disconnected from my launcher.
- FLYING CONDITIONS I will not launch my model rocket in high winds, near buildings, power lines, tall trees, low flying aircraft, or under any conditions which might be dangerous to people or property.

- LAUNCH AREA My model rockets will always be launched from a cleared area, free of any easy to burn materials, and I will only use non-flammable recovery wadding in my rockets.
- JET DEFLECTOR My launcher will have a jet deflector device to prevent the engine exhaust from hitting the ground directly.
- 11. LAUNCH ROD To prevent accidental eye injury I will always place the launcher so the end of the rod is above eye level or cap the end of the rod with my hand when approaching it. I will never place my head or body over the launching rod. When my launcher is not in use I will always store it so that the launch rod is not in an upright position.
- POWER LINES I will never attempt to recover my rocket from a power line or other dangerous place.
- LAUNCH TARGETS & ANGLE I will not launch rockets so their flight path will carry them against targets on the ground, and will never use an explosive warhead nor a payload that is intended to be flammable. My launching device will always be pointed within 30 degrees of vertical.
- 14. PRE-LAUNCH TEST When conducting research activities with unproven designs or methods, I will, when possible, determine their reliability through pre-launch tests. I will conduct launchings of unproven designs in complete isolation from persons not participating in the actual launching.

As a member of the Estes Model Rocketry Program, I promise to faithfully follow all rules of safe conduct as established in the above code.



This Solid Propellant Model Rocketry Safety Code is Approved by The National Association of Rocketry and the Hobby Industry Association of America.



Signed

84710A

REGISTER YOURSELF AS AN OFFICIAL ESTES MODEL ROCKETEER AND RECEIVE A FULL COLOR MODEL ROCKETRY CATALOG!

Register as an official Estes Rocketeer and receive the great new Estes Model Rocketry Catalog. This giant, full color catalog features more than 90 exciting model rocket kits including single and multi-stage vehicles, gliders, scale models, and exotic designs, plus launch equipment, engines, aerial cameras, telemetry devices, and much, much more. Simply fill out the coupon below.

GOESEVEER GEELEVERVION/CAPALOG GEQUEEV

- □ Please register me as an official Estes Rocketeer and rush me your newest Estes catalog. I enclose 50¢ for postage and handling.
- Please send me an Estes Aerospace Club membership brochure and application.
- I have received an Estes Catalog within the last year.

Name _____ Age ____

City_____ State ____ Zip _



Send to: Estes Industries Dept. 188 Penrose, Colorado 81240

		Service Control Species	Zip		Zip	Estes Industries Education Department Department 194 Penrose, Colorado 81240
************		THE RESERVE THE PERSON NAMED IN COLUMN	State	Section of the party of the par	State	Es Send to: Ed Pe
The second of	Teacher's Name	SCHOOL Address	City	My Name	Address	A 5400 CHPP OF CHACK